

N2 generator - PLUMBING schematic (pneumatic)

DRAFT 2026-10-10 - for Tom to verify

Tom's garage PSA nitrogen generator. Towers hold only air today (CMS adsorbent to be added). Gas flow is bottom (air in) to top (product out). Pressures in PSI.

LEGEND

- pipe / hose: seen in the photos or described by the owner
- dashed + '?': ASSUMED, please confirm / correct
- green = valve / output driven by the Arduino
- blue = pressure transducer (PT) to an Arduino analog pin

Gauge = local dial gauge M = manual valve

Names in quotes are labels as seen on the machine

NOTES (Tom, please correct):

- Gas flow is drawn bottom (air in, via the two tower valves) to top (product N2 out).
- Arduino-controlled: V-LEFT D4, V-RIGHT D7, V-FLUSH D11 (location unknown), compressor via SSR D8.
- Manual / autonomous (not Arduino): lever selector, pilot regulator, unload valve, pressure switch.
- Each tower has a pressure sensor, NOT connected (their pins became N2 LOW / N2 HIGH).
- Dashed items are my guesses from photos and the owner's description.

